

Quick Setup Guide for: VSCAN NDT^{PRO} Industrial Film Digitizer



Unpack

- Examine shipping carton for damage. Notify shipper if carton is damaged.
- **Save all packing materials**—carton, foam supports, plastic bags—for reshipping. When reshipping, improper packaging may allow damage to the digitizer, which will incur charges for repair.


Check

- | | |
|---|--|
| <input type="checkbox"/> Digitizer base | <input type="checkbox"/> Power cord: 115V or 230V |
| <input type="checkbox"/> Stand w mounting knobs (2) | <input type="checkbox"/> VSCAN NDT ^{PRO} Industrial Film Digitizer CD |
| <input type="checkbox"/> Film feeder | <input type="checkbox"/> USB cable: 6 foot |
| <input type="checkbox"/> Exit tray | <input type="checkbox"/> Film support bar |

If anything is missing, notify your supplier immediately.

Assemble

- Upside down approach (shown):** Carefully position digitizer upside down. Position stand onto bottom of digitizer. *Note the correct orientation of the rectangle cutout in the stand to the vent pattern in the digitizer's base.* Secure the stand to the digitizer by tightening two included knobs.
 - Upright approach:** Place digitizer on stand. Vent on bottom of digitizer base must be over rectangular cutout on stand's rear bar. Tighten two included knobs to secure digitizer to stand.




2. Attach film feeder to digitizer base:

- a. Note three screws and connector on bottom of feeder. These mate with holes and connector on digitizer base.
- b. Place feeder on top of digitizer base, and slide feeder connector into digitizer connector.
- c. On back of feeder, tighten three thumbscrews to secure feeder to digitizer.



3. Install exit tray by hooking it over notched plastic edge just below rollers. When exit tray is properly positioned, it will be parallel to roller shaft.



Warning: Before you begin the installation procedure, turn off all power to the computer and peripherals.

Précaution: Avant de commencer la connexion, assurez vous que votre ordinateur soit bien éteint.

Advertencia: Antes de continuar con la instalación, favor de apagar su computadora y periférico.

Warnung: Vor dem Installieren den Computer und angeschlossene Geräte ausschalten.

Connect power cord

1. Remove Caution label and connect the power cord to the digitizer's Power Entry Module (PEM), located on the rear of the digitizer.
2. Connect the other end of the power cord to a grounded power outlet.

Do not apply power to the digitizer or connect the digitizer to the PC until you are instructed to do so in the driver installation process.



Install drivers and software

See installation manual on CD for details!

1. Apply power to digitizer first, then apply power to PC. Wait until all three LEDs on front turn green.
2. Insert the VSCAN NDTPRO Industrial Film Digitizer CD into the CD-ROM drive.
3. Double-click NDTPRO_Driver_6.1.exe on the CD to install the driver.

USB cable

Do not connect the other end of the USB cable to the PC until you are prompted to do so during the driver installation process.

Connect the USB cable to the USB port on the digitizer's rear panel.

Important: The USB port on the PC must be USB 2.0 or 3.0. VSCAN does not support the use of USB 1.1 ports.



Information

For more information, see manuals provided on the CD:

- "VSCAN NDTPRO Industrial Film Digitizer Installation Guide"
- "VSCAN NDTPRO Industrial Film Digitizer Installation User's Guide"

Contact

VSCAN Technical Support: Phone: +34 984 030 851.

E-mail: support@iberisoft.com. Web: www.iberisoft.com
